



BELGARD
PAVES THE WAY™

ARTFORMS™

MODULAR PANEL SYSTEM




IDEA BOOK

BENCH & PLANTER







INTERIOR VIEW




NOTE: Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

REQUIRED PANELS


	18 x 36 PANEL	3x
	18 x 36 PANEL	3x
	6 x 36 PANEL	0x
	6 x 36 PANEL	0x

IMPORTANT: 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.






FRONT VIEW



TOP VIEW



REQUIRED HARDWARE

	ANCHOR SLIDE AND NUT	32x
	JOINING PLATE	4x
	OUTER CORNER	12x
	INNER CORNER	0x
	STRETCHER	0x


IMPORTANT: Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

BENCH & VERTICAL PLANTER




INTERIOR VIEW

WOOD FRAME
REFER TO PAGE 18 OF THE
ARTFORMS INSTALLATION
GUIDE




NOTE: Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

REQUIRED PANELS




IMPORTANT: 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.


FRONT VIEW



TOP VIEW



REQUIRED HARDWARE




IMPORTANT: Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.


SMALL BBQ



INTERIOR VIEW




REQUIRED PANELS




IMPORTANT: 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.


FRONT VIEW



TOP VIEW



REQUIRED HARDWARE




IMPORTANT: It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.

LONG BBQ



INTERIOR VIEW




REQUIRED PANELS


	5x
	8x
	2x
	0x

IMPORTANT: 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.

FRONT VIEW



TOP VIEW



REQUIRED HARDWARE

	56x
	14x
	14x
	0x
	0x


IMPORTANT: It is recommended to follow the BBQ manufacturer's specifications for ventilation and clearances. Belgard is not responsible for the conformity of connections, clearances and ventilation. BBQ, countertop and accessories are not included.

RECESSED GAS FIRE PIT



INTERIOR VIEW


The 30 x 30 burner pan is sitting directly on the ARTFORMS hardware, on the corner's brackets.



Ⓢ Cut panel(s) according to the burner manufacturer's specifications for ventilation.


NOTE: The panels 18 x 36 are glued with 6 x 36 using CONSTRUCTION GLUE or STRUCTURE BOND

REQUIRED PANELS




IMPORTANT: 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.


FRONT VIEW



TOP VIEW



REQUIRED HARDWARE




IMPORTANT: It is recommended to follow the burner manufacturer's specifications for ventilation. Belgard is not responsible for the conformity of connections, clearances and ventilation. Burner pan and accessories are not included.

GAS FIRE PIT




INTERIOR VIEW




Ⓢ Add 0.5" thick PLASTIC SHIMS for ventilation

REQUIRED PANELS




IMPORTANT: 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.


FRONT VIEW



TOP VIEW



REQUIRED HARDWARE




IMPORTANT: It is recommended to follow the firekit manufacturer's specifications for ventilation. Belgard is not responsible for the conformity of connections, clearances and ventilation. Burner pan and accessories are not included.

SQUARE PLANTER







INTERIOR VIEW




NOTE: Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

REQUIRED PANELS


	18 x 36 PANEL	0x
	18 x 36 PANEL	4x
	6 x 36 PANEL	4x
	6 x 36 PANEL	0x

IMPORTANT: 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.






FRONT VIEW



TOP VIEW



REQUIRED HARDWARE



	ANCHOR SLIDE AND NUT	40x
	JOINING PLATE	8x
	OUTER CORNER	8x
	INNER CORNER	0x
	STRETCHER	0x

IMPORTANT: Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

RECTANGULAR PLANTER







INTERIOR VIEW




NOTE: Panels "B" can be replaced with panels "A" to equilibrate the pairs/layers. Panels "A" can't be replaced by the panels "B".

REQUIRED PANELS


	18 x 36 PANEL	0x
	18 x 36 PANEL	6x
	6 x 36 PANEL	4x
	6 x 36 PANEL	2x

IMPORTANT: 18 x 36 panels are sold in pair/layer or in full pallet only. 6 x 36 panels are sold per unit or in layer or in full pallet.






FRONT VIEW



TOP VIEW



REQUIRED HARDWARE

	ANCHOR SLIDE AND NUT	56x
	JOINING PLATE	14x
	OUTER CORNER	8x
	INNER CORNER	0x
	STRETCHER	0x

IMPORTANT: Refer to page 23 of the ARTFORMS INSTALLATION GUIDE about the installation of geotextile in planter box. Contact experts/engineers to validate the base preparation, the drainage, the plants & roots growth/management.

